

DV-BP-AC

PLATINUM® FLEX AC ADAPTER

OPERATING INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING THIS PRODUCT.

- 1) Check all AC adapter components and cables for damage before using. If damage is noticed, do not use.
- 2) Only use with compatible JB Industries devices.
- 3) Keep all parts clean and free of debris.
- 4) Do not touch the un-insulated terminals on the connector or short the terminals together. This can cause a fire or electric shock.
- 5) Do not operate the AC adapter on flammable surfaces or near combustible items.
- 6) Disconnect the AC adapter from the power outlet when not in use.
- 7) Protect the AC adapter from heat sources, direct sunlight, and fire.
- 8) Protect the AC adapter from water, rain, and snow. Water increases the risk of electrical shock and damage to the electrical components. Do not use in a damp or wet location.
- 9) Do not disassemble any parts of the AC adapter.
- 10) Properly dispose of a damaged AC adapter according to federal, state, and local regulations.

OPERATION:

- 1) Plug the AC adapter into the outlet. The green light on the power brick should illuminate.
NOTE: If the green light does not turn on, check the AC outlet for voltage. If the AC outlet has the correct voltage, there may be a problem with the AC adapter. Unplug the AC adapter and have it inspected or repaired by qualified personnel.
- 2) Slide the connector into the battery slot of the JB PLATINUM FLEX vacuum pump and press and hold the start button on the pump to turn it on. Press and hold button again to turn off pump.
- 3) When pumping is complete, turn off the pump and slide the connector out of the battery slot and unplug the AC adapter. Do NOT slide the connector out of the battery slot while the pump is running.



WARNING: Improper use can lead to fire hazard, death or serious injuries.

The information contained in this manual is provided for informational purposes only. The information and recommendations are in good faith and are believed to be accurate as of the date of printing. However, JB INDUSTRIES MAKES NO WARRANTY, EITHER EXPRESSED OR IMPLIED, WITH RESPECT TO THIS INFORMATION AND DISCLAIMS ALL LIABILITY FROM RELIANCE ON IT.



JB INDUSTRIES
800.323.0811 JBIND.COM SALES@JBIND.COM