

Featured Product Specials



Oil Transfer Pump T30251

Oil Transfer pumps are used for removing oil for recovery and conversion or to add oil to existing systems. Designed to pump oil into the system while the unit is operating without shutting down for charging, the oil transfer pump smoothly pumps oil into the compressor on the downstroke while the system is under pressure resulting in easier pumping on the positive stroke. The universal tapered rubber adapter is designed to fit all 1, 2½, and 5 gallon containers without additional adapters. The transfer pump works against 200 psi of pressure and is compatible with all oil types including synthetic, mineral, and polyol ester. Our pump features an automatic bleed valve with no moving parts that equalizes pressure inside and outside of the oil container. Pumps 2.6 ounces (78 ml) per stroke.



Side Can Tap SCT-1050

The design of our side can tap allows you to easily adjust from R-12 to R-134a refrigerant cans for quick and easy charging. The collars are attached resulting in no loose parts to lose. To use, simply slide the appropriate collar around the refrigerant can and close handles to pierce. Please note, our side can tap is not to be used with any refrigerants other than R-12 and R-134a.

JUST BETTER

Aurora, Il 60507 www.jbind.com 800.323.0811 sales@jbind.com

